


Danmar Hensinger Neck Orthoses

Size	A: Inner circumference of collar (measure neck circumference)	B: Height of collar (measure form earlobe to shoulder, minus 1.2cm)
Extra Small	22.8cm (9")	2.5cm (1")
Small	30.5cm (12")	3.8cm (1.5")
Medium	35.5cm (14")	5.0cm (2")
Large	40.5cm (16")	6.3cm (2.5")

A - Circumference
B - Height
C - Width



See the "Ready-To-Wear Hensinger Collar Order Form" found under Downloads - Forms - Danmar Hensinger on the Well & Able website for additional detail.

